


HAMMOCK UNDER BLANKET SET UP INSTRUCTIONS

(HAMMOCK INSULATION ACCESSORY)


NOT DESIGNED TO BE LOAD BEARING. YOUR HAMMOCK SHOULD TAKE YOUR WEIGHT, NOT THE BLANKET

1. SET UP YOUR HAMMOCK

SET UP YOUR HAMMOCK IN ACCORDANCE WITH THE MANUFACTURER'S INSTRUCTIONS



2. SET UP THE BLANKET




LAY OUT YOUR BLANKET
TAKE THE MIDDLE (A) SHOCK CORDS TO CREATE SLIP KNOTS IN BOTH SETS AND AT BOTH ENDS (A).
LEAVE THE REMAINING SHOCK CORDS (B) FOR NOW.


3. HOOK UP THE BLANKET (A)

UNHOOK ONE END OF YOUR HAMMOCK AND PASS THE SLIP KNOT LOOP (A) THROUGH THE CARABINER YOU HAVE USED FOR YOUR HAMMOCK SUPPORT SYSTEM. DO THE SAME WITH THE OTHER SIDE AND AT THE OTHER ENDS (A)

MAKE SURE YOU DON'T PULL TOO TIGHT. THE UNDER BLANKET SHOULD LOOSELY HANG BELOW YOUR HAMMOCK SYSTEM.




THE UNDER BLANKET SHOULD BE CENTRED EITHER SIDE AND SHOCK CORDS (A) TIED LOOSELY TO THE CARABINER NOT TOO TIGHT



4. HOOK UP OUTSIDE SHOCK CORDS (B)

DEPENDING ON YOUR HAMMOCK SYSTEM, IF REQUIRED THE REMAINING SHOCK CORDS (B) CAN BE ATTACHED AROUND THE TREE TO BRING THE HAMMOCK INTO SHAPE.



5. CHECK TENSION BEFORE USING

SET-UP NOTE

It is very important BEFORE you use the Hammock insulation system that you check the tension by lightly pressing down. THE UNDERBLANKET IS NOT DESIGNED TO BE LOAD BEARING. YOUR HAMMOCK SHOULD TAKE YOUR WEIGHT, NOT THE UNDERBLANKET.

ADJUST TENSION AS NECESSARY BEFORE LYING IN THE HAMMOCK.

CLIMB INTO THE HAMMOCK AS USUAL. THE UNDER BLANKET SHOULD HANG UNDERNEATH YOU. YOU DON'T WANT TO BE PRESSING DOWN ON IT OR YOU WILL COMPRESS THE INSULATION AND REDUCE THE THERMAL PERFORMANCE.

